



MOTOMA®

Power into the Future

USER MANUAL



AXPERT VM III TWIN 4KW/6KW SOLAR INVERTER

Table Of Contents

| | |
|---|-----------|
| ABOUT THIS MANUAL | 1 |
| Purpose..... | 1 |
| Scope | 1 |
| SAFETY INSTRUCTIONS | 1 |
| INTRODUCTION | 2 |
| Features | 2 |
| Basic System Architecture | 2 |
| Product Overview..... | 3 |
| INSTALLATION | 4 |
| Unpacking and Inspection..... | 4 |
| Preparation | 4 |
| Mounting the Unit..... | 4 |
| Battery Connection | 5 |
| AC Input/Output Connection | 7 |
| PV Connection | 8 |
| Final Assembly..... | 10 |
| Remote Display Panel Installation | 11 |
| Communication Options..... | 12 |
| BMS Communication | 12 |
| Dry Contact Signal | 13 |
| OPERATION | 14 |
| Power ON/OFF | 14 |
| Operation and Display Panel | 14 |
| LCD Display Icons | 15 |
| LCD Setting..... | 17 |
| Display Setting | 32 |
| Operating Mode Description | 38 |
| Battery Equalization Description..... | 41 |
| Fault Reference Code | 42 |
| Warning Indicator | 43 |
| CLEARANCE AND MAINTENANCE FOR ANTI-DUST KIT | 44 |
| Overview | 44 |
| Clearance and Maintenance | 44 |
| SPECIFICATIONS | 45 |
| Table 1 Line Mode Specifications | 45 |
| Table 2 Inverter Mode Specifications | 46 |
| Table 3 Charge Mode Specifications | 47 |
| Table 4 General Specifications | 47 |
| TROUBLE SHOOTING | 48 |
| Appendix I: BMS Communication Installation | 49 |
| Appendix II: The Wi-Fi Operation Guide in Remote Panel | 57 |

ABOUT THIS MANUAL

Purpose

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations. Keep this manual for future reference.

Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

SAFETY INSTRUCTIONS



WARNING: All safety instructions in this document must be read, understood and followed. Failure to follow these instructions will result in death or serious injury.

1. Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
2. **CAUTION** --To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
3. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. **CAUTION** – Only qualified personnel can install this device with battery.
6. **NEVER** charge a frozen battery.
7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
10. One piece of 150A fuse is provided as over-current protection for the battery supply.
11. **GROUNDING INSTRUCTIONS** -This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. **NEVER** cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
13. **Warning!!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.
14. **WARNING:** Because this inverter is non-isolated, only three types of PV modules are acceptable: single crystalline, poly crystalline with class A-rated and CIGS modules. To avoid any malfunction, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using CIGS modules, please be sure NO grounding.
15. **CAUTION:** It's requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

INTRODUCTION

This is a multi-function inverter, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support in a single package. The comprehensive LCD display offers user-configurable and easy-accessible button operations such as battery charging current, AC or solar charging priority, and acceptable input voltage based on different applications.

Features

- Pure sine wave inverter
- Feed-in to the grid function
- Configurable input voltage ranges for home appliances and personal computers via LCD control panel
- Configurable battery charging current based on applications via LCD control panel
- Configurable AC/Solar Charger priority via LCD control panel
- Compatible to utility mains or generator power
- Auto restart while AC is recovering
- Overload / Over temperature / short circuit protection
- Smart battery charger design for optimized battery performance
- Cold start function
- Removable LCD control module
- Multiple communication ports for BMS (RS485, CAN-BUS, RS232)
- Built-in WiFi for mobile monitoring (Requires App), OTG USB function, dusk filters
- Configurable AC/PV Output usage timer and prioritization

Basic System Architecture

The following illustration shows basic application for this unit. It also required the following devices to have a complete running system:

- Generator or Utility mains.
- PV modules

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power various appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioners.





Figure 1 Solar Power System

Product Overview



1. LCD display
2. Status indicator
3. Charging indicator
4. Fault indicator
5. Function buttons
6. Power on/off switch
7. AC input connectors
8. AC output connectors (Load connection)
9. PV input
10. Battery input
11. Circuit breaker
12. Remote LCD panel communication port
13. Dry contact
14. USB communication port
15. BMS communication port: CAN and RS232 or RS485
16. RS-232 communication port
17. Output source indicators (refer to OPERATION/Operation and Display Panel section for details) and USB function setting reminder (refer to OPERATION/Function Setting for the details)
18. RGB LED

INSTALLATION


Unpacking and Inspection

Before installation, please inspect the content. Be sure that nothing inside the package is damaged. You should have received the following items inside the package:

- Inverter x 1
- User manual x 1
- RS232 Communication cable x 1
- Software CD x 1
- DC Fuse x 1

Preparation


Before connecting all wirings, please take off the bottom cover by removing two screws as shown below. Detach the cables from the cover.



Mounting the Unit


Consider the followings before selecting your placements:

- Do not mount the inverter on flammable construction materials.
- Mount on a solid surface
- Install the inverter at eye level in order to allow easy LCD display readout.
- For proper air circulation and heat dissipation, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit.
- The ambient temperature should be between 0°C and 55°C to ensure optimal operation.
- The recommended orientation is to be adhered to the wall vertically. Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and to have enough space for wirings.



SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Install the unit by screwing two screws. It's recommended to use M4 or M5 screws.




Battery Connection

CAUTION: For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnection device between battery and the inverter. It may not be necessary to have a disconnection device in some applications, however, it's still recommended to have over-current protection installed. Please refer to typical amperage as required.

WARNING! All wiring must be performed by a qualified electrical technician.

WARNING! It's very important for system safety and efficient operation to use appropriate cables for battery connection. To reduce risk of injury, please use the proper recommended cable in the table below.

Ring terminal:




Recommended battery cable size:



| Model | Typical Amperage | Wire Size | Cable mm ² (each) | Ring Terminal Dimensions | | Torque Value |
|-------|------------------|-----------|------------------------------|--------------------------|--------|--------------|
| | | | | D (mm) | L (mm) | |
| | | | | 4KW | 165A | |
| 6KW | 124A | 1*2AWG | 38 | 8.4 | 39.2 | |
| | | 2*4AWG | 25 | 8.4 | 33.2 | |

Please follow below steps to implement battery connection:


1. 4KW model supports 24VDC system and 6KW model supports 48VDC system. Connect all battery packs as below chart. It is recommend to connect minimum of 100Ah capacity battery for 4KW model and 200Ah capacity battery for 6KW model.




- Prepare four battery wires for 4KW model and two or four battery wires for 6KW model depending on cable size (refer to recommended cable size table). Apply ring terminals to your battery wires and secure it to the battery terminal block with the bolts properly tightened. Refer to battery cable size for torque value. Make sure polarity at both the battery and the inverter is correctly connected and ring terminals are secured to the battery terminals.




4KW / 6KW



6KW

| | |
|---|---|
|  | <p>WARNING: Shock Hazard Installation must be performed with care due to high battery voltage in series.</p> |
|---|---|

| | |
|---|--|
|  | <p>CAUTION!! Do not place anything between inverter terminals and the ring terminals. Otherwise, overheating may occur.</p> <p>CAUTION!! Do not apply anti-oxidant substance on the terminals before terminals are securely tightened.</p> <p>CAUTION!! Before making final DC connection or closing DC breaker/disconnector, be sure that the positive (+) must be connected to positive (+) and negative (-) connected to negative (-).</p> |
|---|--|

AC Input/Output Connection

CAUTION!! Before connecting to AC input power source, please install a **separate** AC breaker between the inverter and the AC input power source. This will ensure that the inverter can be safely disconnected during maintenance and fully protected from over-current. The recommended spec of AC breaker is 32A

CAUTION!! There are two power terminal blocks with "IN" (Input) and "OUT" (Output) markings. DO NOT mistakenly connect to the wrong connectors.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable size for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

Suggested cable requirement for AC wires

| Model | Gauge | Cable (mm ²) | Torque Value |
|-------|--------|--------------------------|--------------|
| 4KW | 12 AWG | 4 | 1.2 Nm |
| 6KW | 10 AWG | 6 | 1.2 Nm |


Please follow these steps to implement AC input/output connection:

1. Before making AC input/output connection, be sure to enable DC protector or disconnecter first.
2. Remove insulation sleeves for about 10mm for the five screw terminals.
3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect the grounding wire (⊕) first.

⊕ → **Ground (yellow-green)**

L → **LINE (brown or black)**

N → **Neutral (blue)**



WARNING:

Be sure that AC power source is disconnected before attempting to hardwire it to the unit.

4. This inverter is equipped with dual-output. There are four terminals (L1/N1, L2/N2) available on output port. It's set up through LCD program or monitoring software to turn on and off the second output. Refer to "LCD setting" section for the details.

Insert AC output wires according to polarities indicated on terminal block and tighten terminal screws. Be sure to connect PE protective conductor (⊕) first.


⊕ → **Ground (yellow-green)**

L1 → **LINE (brown or black)**

N1 → **Neutral (blue)**

L2 → **LINE (brown or black)**

N2 → **Neutral (blue)**



5. Make sure the wires are securely connected.

CAUTION: Appliances such as air conditioner required at least 2~3 minutes to spool up because it needs to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short period of time, it may cause damage to your connected appliances. To prevent this from happening, please check with manufacturer of air conditioner if it has time-delay function before installation. Otherwise, this inverter will trigger overload fault and cut off output to protect your appliance but sometimes it may still causes damage to the air conditioner.

PV Connection

CAUTION: Before connecting to PV modules, please install **separately** DC circuit breakers between inverter and PV modules.

NOTE1: Please use 600VDC/30A circuit breaker.

NOTE2: The overvoltage category of the PV input is II.

Please follow the steps below to implement PV module connection:

WARNING: Because this inverter is non-isolated, only three types of PV modules are acceptable: single crystalline and poly crystalline with class A-rated and CIGS modules.

To avoid any malfunction, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using CIGS modules, please be sure NO grounding.

CAUTION: It's required to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

Step 1: Check the input voltage of PV array modules. This system is applied with two strings of PV array. Please make sure that the maximum current load of each PV input connector is 18A.




CAUTION: Exceeding the maximum input voltage can destroy the unit!! Check the system before wire connection.

Step 2: Disconnect the circuit breaker and switch off the DC switch.

Step 3: Assemble provided PV connectors with PV modules by the following steps.


Components for PV connectors and Tools:

| | |
|--------------------------|---|
| Female connector housing |  |
| Female terminal |  |

| | |
|---------------------------|---|
| Male connector housing |  |
| Male terminal |  |
| Crimping tool and spanner |  |

Prepare the cable and follow the connector assembly process:

Strip one cable 8 mm on both end sides and be careful NOT to nick conductors.



Insert striped cable into female terminal and crimp female terminal as shown below.



Insert assembled cable into female connector housing as shown below.



Insert striped cable into male terminal and crimp male terminal as shown below.




Insert assembled cable into male connector housing as shown below.



Then, use spanner to screw pressure dome tightly to female connector and male connector as shown below.



Step 4: Check correct polarity of connection cable from PV modules and PV input connectors. Then, connect positive pole (+) of connection cable to positive pole (+) of PV input connector. Connect negative pole (-) of connection cable to negative pole (-) of PV input connector.



WARNING! For safety and efficiency, it's very important to use appropriate cables for PV module connection. To reduce risk of injury, please use the proper cable size as recommended below.

| Conductor cross-section (mm ²) | AWG no. |
|--|---------|
| 4~6 | 10~12 |

CAUTION: Never directly touch the terminals of inverter. It might cause lethal electric shock.

PV Module Selection:

When selecting proper PV modules, please be sure to consider the following parameters:

1. Open circuit Voltage (Voc) of PV modules not to exceeds maximum PV array open circuit voltage of the inverter.
2. Open circuit Voltage (Voc) of PV modules should be higher than the start-up voltage.

| | | |
|---|-----------------|-------|
| INVERTER MODEL | 4KW | 6KW |
| Max. PV Array Power | 5000W | 6000W |
| Max. PV Array Open Circuit Voltage | 500Vdc | |
| PV Array MPPT Voltage Range | 60Vdc~450Vdc | |
| Start-up Voltage | 60Vdc +/- 10Vdc | |
| Max. PV Current | 27A | |

Take the 250Wp PV module as an example. After considering above two parameters, the recommended module configurations are listed in the table below.


| | | | | |
|--|---|--|----------------|-------------------|
| Solar Panel Spec. (reference) - 250Wp - Vmp: 30.1Vdc - Imp: 8.3A - Voc: 37.7Vdc - Isc: 8.4A - Cells: 60 | SOLAR INPUT | | Q'ty of panels | Total input power |
| | Min in series: 2 pcs, max. in series: 12 pcs. | | | |
| | 2pcs in series | | 2 pcs | 500W |
| | 4pcs in series | | 4 pcs | 1000W |
| | 6 pcs in series | | 6 pcs | 1500W |
| | 8 pcs in series | | 8 pcs | 2000W |
| | 12 pcs in series | | 12 pcs | 3000W |
| | 8 pieces in series and 2 sets in parallel | | 16 pcs | 4000W |
| | 10 pieces in series and 2 sets in parallel | | 20 pcs | 5000W |
| | 11 pieces in series and 2 sets in parallel (only for 6KVA model) | | 22 pcs | 5500W |
| | 12 pieces in series and 2 sets in parallel (only for 6KVA model) | | 24 pcs | 6000W |

Take the 555Wp PV module as an example. After considering above two parameters, the recommended module configurations are listed in the table below.

| | | | | |
|--|---|--|----------------|-------------------|
| Solar Panel Spec. (reference) - 555Wp - Imp: 17.32A - Voc: 38.46Vdc - Isc: 18.33A - Cells: 110 | SOLAR INPUT | | Q'ty of panels | Total input power |
| | Min in series: 2 pcs, max. in series: 11 pcs. | | | |
| | 2pcs in series | | 2 pcs | 1110W |
| | 4pcs in series | | 4 pcs | 2220W |
| | 6 pcs in series | | 6 pcs | 3330W |
| | 8 pcs in series | | 8 pcs | 4440W |
| | 10 pcs in series | | 10 pcs | 5550W |
| | 11 pcs in series | | 11 pcs | 6000W |

Final Assembly


After connecting all wirings, replace the bottom cover as shown below.




Remote Display Panel Installation

The LCD module can be removable and installed in a remote location with an optional communication cable. Please take the follow steps to implement this remote panel installation.


Step 1. Remove the screw on the bottom of LCD panel and pull down the module from the case. Detach the cable from the remote communication port. Be sure to replace the retention plate back to the inverter.




Step 2. Prepare your mounting holes in the marked locations as shown in the illustration below. The LCD module then can be securely mounted to your desired location.



Note: Wall installation should be implemented with the proper screws to the right.



Step 3. Connect LCD module to the inverter with an optional RJ45 communication cable as shown below.



Communication Options

Serial Connection

Please use the supplied serial cable to connect between the inverter and your PC. Install the monitoring software from the bundled CD and follow the on-screen instructions to complete your installation. For detailed software operation, refer to the software user manual on the bundled CD.

Wi-Fi Connection


This unit is equipped with a Wi-Fi transmitter. Wi-Fi transmitter can enable wireless communication between off-grid inverters and monitoring platform. Users can access and control the monitored inverter with downloaded APP. You may find "MOTOMA" app from the Apple® Store or Google® Play Store. All data loggers and parameters are saved in iCloud. For quick installation and operation, please check Appendix C.

BMS Communication

It is recommended to purchase a special communication cable if you are connecting to Lithium-Ion battery banks. Please refer to Appendix B- BMS Communication Installation for details.


Dry Contact Signal

There is one dry contact (3A/250VAC) available on the rear panel. It could be used to deliver signal to external device when battery voltage reaches warning level.

| Unit Status | Condition | |  Dry contact port: NC C NO | | |
|-------------|---|---|--|--------|-------|
| | | | NC & C | NO & C | |
| Power Off | Unit is off and no output is powered. | | Close | Open | |
| Power On | Output is powered from Battery power or Solar energy. | Program 01 set as USB (utility first) | Battery voltage < Low DC warning voltage | Open | Close |
| | | | Battery voltage > Setting value in Program 13 or battery charging reaches floating stage | Close | Open |
| | | Program 01 is set as SBU (SBU priority) | Battery voltage < Setting value in Program 12 | Open | Close |
| | | | Battery voltage > Setting value in Program 13 or battery charging reaches floating stage | Close | Open |

OPERATION

Power ON/OFF



Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the LCD module) to turn on the unit.


Inverter Turn-on

After this inverter is turned on, WELCOME light show will be started with RGB LED. It will slowly cycle through entire spectrum of nine colors (Green, Sky blue, Royal blue, Violet, Pink, Red, Honey, Yellow, Lime yellow) about 10-15 seconds. After initialization, it will light up with default color.

RGB LED can light up in different color and light effects based on the setting of energy priority to display the operation mode, energy source, battery capacity and load level. These parameters such as color, effects, brightness, speed and so on can be configured through the LCD panel. Please refer to LCD settings for the details.



Operation and Display Panel

The operation and the LCD module, shown in the chart below, includes six indicators, six function keys, on/off switch and a LCD display, indicating the operating status and input/output power information.









Indicators


| LED Indicator | Color | Solid/Flashing | Messages |
|---------------|-------|----------------|---------------------------|
| Setting LED 1 | Green | Solid On | Output powered by utility |
| Setting LED 2 | Green | Solid On | Output powered by PV |








| | | | | |
|--------------------------|---|-------|----------|--|
| Setting LED 3 | | Green | Solid On | Output powered by battery |
| Status indicators |  | Green | Solid On | Output is available in line mode |
| | | | Flashing | Output is powered by battery in battery mode |
| |  | Green | Solid On | Battery is fully charged |
| | | | Flashing | Battery is charging. |
| | FAULT | Red | | Solid On |
| | | | Flashing | Warning mode |

Function Keys






| Function Key | Description | |
|---|---|---|
|  | ESC | Exit the setting |
| | USB function setting | Select USB OTG functions |
|  | Timer setting for the Output source priority | Setup the timer for prioritizing the output source |
|  | Timer setting for the Charger source priority | Setup the timer for prioritizing the charger source |
|  | Up | To last selection |
|  | Down | To next selection |
|  | Enter | To confirm/enter the selection in setting mode |

LCD Display Icons



| Icon | Function description |
|---|--|
| Input Source Information | |
|  | Indicates the AC input. |
|  | Indicates the PV input |
|  | Indicate input voltage, input frequency, PV voltage, charger current, charger power, battery voltage. |
| Configuration Program and Fault Information | |
|  | Indicates the setting programs. |
|  | Indicates the warning and fault codes. |
|  | Warning:  flashing with warning code. |

| | | Fault: F88 lighting with fault code | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|-------------|---|--------------|-----------------------------|--------------------------|--|---------------------------|---|---|----------------|--|---------------|----------------|---------------------------|-------------|---------------------------|-------------|---------------|-------------|--|--|
| Output Information | | | | | | | | | | | | | | | | | | | | | | | |
| | Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current. | | | | | | | | | | | | | | | | | | | | | | |
| OUTPUT | The ICON flashing that indicate the unit with AC output and setting Programs 60, 61 or 62 different to default setting. | | | | | | | | | | | | | | | | | | | | | | |
| Battery Information | | | | | | | | | | | | | | | | | | | | | | | |
| BATT | Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode. | | | | | | | | | | | | | | | | | | | | | | |
| When battery is charging, it will present battery charging status. | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Status</th> <th>Battery voltage</th> <th>LCD Display</th> </tr> </thead> <tbody> <tr> <td rowspan="3">Constant Current mode / Constant Voltage mode</td> <td><2V/cell</td> <td>4 bars will flash in turns.</td> </tr> <tr> <td>2 ~ 2.083V/cell</td> <td>The right bar will be on and the other three bars will flash in turns.</td> </tr> <tr> <td>2.083 ~ 2.167V/cell</td> <td>The right two bars will be on and the other two bars will flash in turns.</td> </tr> <tr> <td>Floating mode. Batteries are fully charged.</td> <td>> 2.167 V/cell</td> <td>The right three bars will be on and the left bar will flash.</td> </tr> </tbody> </table> | Status | Battery voltage | LCD Display | Constant Current mode / Constant Voltage mode | <2V/cell | 4 bars will flash in turns. | 2 ~ 2.083V/cell | The right bar will be on and the other three bars will flash in turns. | 2.083 ~ 2.167V/cell | The right two bars will be on and the other two bars will flash in turns. | Floating mode. Batteries are fully charged. | > 2.167 V/cell | The right three bars will be on and the left bar will flash. | | | | | | | | | | |
| Status | Battery voltage | LCD Display | | | | | | | | | | | | | | | | | | | | | |
| Constant Current mode / Constant Voltage mode | <2V/cell | 4 bars will flash in turns. | | | | | | | | | | | | | | | | | | | | | |
| | 2 ~ 2.083V/cell | The right bar will be on and the other three bars will flash in turns. | | | | | | | | | | | | | | | | | | | | | |
| | 2.083 ~ 2.167V/cell | The right two bars will be on and the other two bars will flash in turns. | | | | | | | | | | | | | | | | | | | | | |
| Floating mode. Batteries are fully charged. | > 2.167 V/cell | The right three bars will be on and the left bar will flash. | | | | | | | | | | | | | | | | | | | | | |
| In battery mode, it will present battery capacity. | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Load Percentage</th> <th>Battery Voltage</th> <th>LCD Display</th> </tr> </thead> <tbody> <tr> <td rowspan="4">Load > 50%</td> <td>< 1.85V/cell</td> <td>LOWBATT </td> </tr> <tr> <td>1.85V/cell ~ 1.933V/cell</td> <td>BATT </td> </tr> <tr> <td>1.933V/cell ~ 2.017V/cell</td> <td>BATT </td> </tr> <tr> <td>> 2.017V/cell</td> <td>BATT </td> </tr> <tr> <td rowspan="4">Load < 50%</td> <td>< 1.892V/cell</td> <td>LOWBATT </td> </tr> <tr> <td>1.892V/cell ~ 1.975V/cell</td> <td>BATT </td> </tr> <tr> <td>1.975V/cell ~ 2.058V/cell</td> <td>BATT </td> </tr> <tr> <td>> 2.058V/cell</td> <td>BATT </td> </tr> </tbody> </table> | Load Percentage | Battery Voltage | LCD Display | Load > 50% | < 1.85V/cell | LOWBATT | 1.85V/cell ~ 1.933V/cell | BATT | 1.933V/cell ~ 2.017V/cell | BATT | > 2.017V/cell | BATT | Load < 50% | < 1.892V/cell | LOWBATT | 1.892V/cell ~ 1.975V/cell | BATT | 1.975V/cell ~ 2.058V/cell | BATT | > 2.058V/cell | BATT | | |
| Load Percentage | Battery Voltage | LCD Display | | | | | | | | | | | | | | | | | | | | | |
| Load > 50% | < 1.85V/cell | LOWBATT | | | | | | | | | | | | | | | | | | | | | |
| | 1.85V/cell ~ 1.933V/cell | BATT | | | | | | | | | | | | | | | | | | | | | |
| | 1.933V/cell ~ 2.017V/cell | BATT | | | | | | | | | | | | | | | | | | | | | |
| | > 2.017V/cell | BATT | | | | | | | | | | | | | | | | | | | | | |
| Load < 50% | < 1.892V/cell | LOWBATT | | | | | | | | | | | | | | | | | | | | | |
| | 1.892V/cell ~ 1.975V/cell | BATT | | | | | | | | | | | | | | | | | | | | | |
| | 1.975V/cell ~ 2.058V/cell | BATT | | | | | | | | | | | | | | | | | | | | | |
| | > 2.058V/cell | BATT | | | | | | | | | | | | | | | | | | | | | |
| Load Information | | | | | | | | | | | | | | | | | | | | | | | |
| | Indicates overload. | | | | | | | | | | | | | | | | | | | | | | |
| LOAD | Indicates the load level by 0-24%, 25-49%, 50-74% and 75-100%. | | | | | | | | | | | | | | | | | | | | | | |
| | 0%~24% | 25%~49% | | | | | | | | | | | | | | | | | | | | | |
| | LOAD | LOAD | | | | | | | | | | | | | | | | | | | | | |
| | 50%~74% | 75%~100% | | | | | | | | | | | | | | | | | | | | | |
| | LOAD | LOAD | | | | | | | | | | | | | | | | | | | | | |
| Mode Operation Information | | | | | | | | | | | | | | | | | | | | | | | |
| | Indicates unit connects to the mains. | | | | | | | | | | | | | | | | | | | | | | |
| | Indicates unit connects to the PV panel. | | | | | | | | | | | | | | | | | | | | | | |
| BYPASS | Indicates load is supplied by utility power. | | | | | | | | | | | | | | | | | | | | | | |
| | Indicates the utility charger circuit is working. | | | | | | | | | | | | | | | | | | | | | | |





| | |
|---|--|
|  | Indicates the solar charger circuit is working. |
|  | Indicates the DC/AC inverter circuit is working. |
|  | Indicates unit alarm is disabled. |
|  | Indicates USB disk is connected. |
|  | Indicates timer setting or time display |









LCD Setting

General Setting

After pressing and holding “←” button for 3 seconds, the unit will enter the Setup Mode. Press “▲” or “▼” button to select setting programs. Press “←” button to confirm you selection or “⏏/↺” button to exit.








Setting Programs:











| Program | Description | Selectable option |
|---------|--|--|
| 00 | Exit setting mode | Escape 00  ESC |
| 01 | Output source priority: To configure load power source priority | Utility first (default) 01  USB Utility will provide power to the loads as first priority. Solar and battery energy will provide power to the loads only when utility power is not available. |
| | | Solar first 01  SUB Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, Utility energy will supply power to the loads at the same time. |
| | | SBU priority 01  SbU Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12. |






| | | | |
|----|---|--|--|
| 02 | Maximum charging current: To configure total charging current for solar and utility chargers. (Max. charging current = utility charging current + solar charging current) | 60A (default) 02  60 ^A | Setting range is from 10A to 120A. Increment of each click is 10A. |
| 03 | AC input voltage range | Appliances (default) 03  APL | If selected, acceptable AC input voltage range will be within 90-280VAC. |
| | | UPS 03  UPS | If selected, acceptable AC input voltage range will be within 170-280VAC. |
| 05 | Battery type | AGM (default) 05  AGM | Flooded 05  FLD |
| | | User-Defined 05  USE | If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 26, 27 and 29. |
| | | Pylontech battery 05  PYL | If selected, programs of 02, 26, 27 and 29 will be automatically set up. No need for further setting. |
| | | WECO battery (only for 48V model) 05  WEC | If selected, programs of 02, 12, 26, 27 and 29 will be auto-configured per battery supplier recommended. No need for further adjustment. |

| | | | |
|----|---|---|---|
| 05 | Battery type | Soltaro battery (only for 48V model) 05 | If selected, programs of 02, 26, 27 and 29 will be automatically set up. No need for further setting. |
| | | SOL | |
| | | LIb-protocol compatible battery 05 | Select "LIb" if using Lithium battery compatible to Lib protocol. If selected, programs of 02, 26, 27 and 29 will be automatically set up. No need for further setting. |
| | | LIb | |
| | | 3 rd party Lithium battery 05 | Select "LIC" if using Lithium battery not listed above. If selected, programs of 02, 26, 27 and 29 will be automatically set up. No need for further setting. Please contact the battery supplier for installation procedure. |
| | | LIC | |
| 06 | Auto restart when overload occurs | Restart disable (default) 06 | Restart enable 06 |
| | | Lfd | Lfe |
| 07 | Auto restart when over temperature occurs | Restart disable (default) 07 | Restart enable 07 |
| | | ftd | fte |
| 09 | Output frequency | 50Hz (default) 09 | 60Hz 09 |
| | | 50 _{Hz} | 60 _{Hz} |
| 10 | Output voltage | 220V 10 | 230V (default) 10 |
| | | 220 _v | 230 _v |












| | | | |
|----|---|---|---|
| | | 240V 10 | |
| 11 | Maximum utility charging current Note: If setting value in program 02 is smaller than that in program in 11, the inverter will apply charging current from program 02 for utility charger. | 240 _v 30A (default) 11 U61 30 _A | Setting range is 2A, then from 10A to 100A. Increment of each click is 10A. |
| 12 | Setting voltage or SOC percentage back to utility source when selecting "SBU" (SBU priority) in program 01. | 23V (default for 24V model) 12 BATT 230 _v | Setting range is from 22V to 25.5V. Increment of each click is 1V. |
| | | 46V (default for 48V model) 12 BATT 460 _v | Setting range is from 44V to 55V. Increment of each click is 1V. |
| | | SOC 10% (default for Lithium) 12 SOC BATT 10% | If any types of lithium battery is selected in program 05, setting value will change to SOC automatically. Adjustable range is 5% to 95%. |
| 13 | Setting voltage or SOC percentage back to battery mode when selecting "SBU" (SBU priority) in program 01. | Available options for 24V model: Setting range is FUL and from 24V to 29V. Increment of each click is 1V. | |
| | | Battery fully charged 13 BATT FUL _v | 27V (default) 13 BATT 270 _v |
| | | Available options for 48V model: Setting range is FUL and from 48V to 58V. Increment of each click is 1V. | |
| | | Battery fully charged 13 BATT FUL _v | 54V (default) 13 BATT 54 _v |







| | | | |
|----|--|--|---|
| | | SOC 80% (default for Lithium)  | If any types of lithium battery is selected in program 05, setting value will change to SOC automatically. Adjustable range is 10% to 100%. Increment of each click is 5%. |
| 16 | Charger source priority: To configure charger source priority | If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below: Solar first  | Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available. |
| | | Solar and Utility (default)  | Solar energy and utility will charge battery at the same time. |
| | | Only Solar  | Solar energy will be the only charger source no matter utility is available or not. |
| | | If this inverter/charger is working in Battery mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient. | |
| 18 | Alarm control | Alarm on (default)  | Alarm off  |
| | | Return to default display screen (default)  | If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage /output voltage) after no button is pressed for 1 minute. |
| 19 | Auto return to default display screen | | |














| | | | |
|----|---|--|--|
| | | Stay at latest screen 19  LFP | If selected, the display screen will stay at latest screen user finally switches. |
| 20 | Backlight control | Backlight on (default) 20  LON | Backlight off 20  LOF |
| 22 | Beeps while primary source is interrupted | Alarm on (default) 22  RON | Alarm off 22  ROF |
| 23 | Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode. | Bypass disable (default) 23  bYd | Bypass enable 23  bYE |
| 25 | Record Fault code | Record enable (default) 25  FEN | Record disable 25  FdS |
| 26 | Bulk charging voltage (C.V voltage) | Available options for 24V model: | |
| | | 28.2V (default) 26  CV BATT 28.2 _v | If user-defined is selected in program 5, this program can be set up. Setting range is from 25.0V to 31.5V. Increment of each click is 0.1V. |




| | | | |
|----|---|--|--|
| 26 | Bulk charging voltage (C.V voltage) | Available options for 48V model: | |
| | | 56.4V (default)  | If user-defined is selected in program 5, this program can be set up. Setting range is from 48.0V to 61.0V. Increment of each click is 0.1V. |
| 27 | Floating charging voltage | Available options for 24V model: | |
| | | 27V (default)  | If user-defined is selected in program 5, this program can be set up. Setting range is from 25.0V to 31.5V. Increment of each click is 0.1V. |
| | | Available options for 48V model: | |
| | | 54V (default)  | If user-defined is selected in program 5, this program can be set up. Setting range is from 48.0V to 61.0V. Increment of each click is 0.1V. |
| 29 | Low DC cut-off voltage or SOC percentage: <ul style="list-style-type: none"> ● If battery power is only power source available, inverter will shut down. ● If PV energy and battery power are available, inverter will charge battery without AC output. ● If PV energy, battery power and utility are all available, inverter will transfer to line mode | Available options for 24V model: | |
| | | 21.0V (default)  | If user-defined is selected in program 5, this program can be set up. Setting range is from 21.0V to 24.0V. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected. |
| | | Available options for 48V model: | |
| | | 42.0V (default)  | If user-defined is selected in program 5, this program can be set up. Setting range is from 42.0V to 48.0V. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected. |

| | | | |
|----|------------------------------|---|---|
| | | SOC 0% (default) 29 ⚙️ SOC BATT 0% | If Lithium battery is selected in program 5, setting value will change to SOC automatically. Setting range is from 0% to 90%. |
| 30 | Battery equalization | Battery equalization 30 ⚙️ EEN | Battery equalization disable (default) 30 ⚙️ EdS |
| | | If "Flooded" or "User-Defined" is selected in program 05, this program can be set up. | |
| 31 | Battery equalization voltage | Available options for 24V model: | |
| | | 29.2V (default) 31 ⚙️ EV BATT 29.2 _v | Setting range is from 25.0V to 31.5V. Increment of each click is 0.1V. |
| | | Available options for 48V model: | |
| | | 58.4V (default) 31 ⚙️ EV BATT 58.4 _v | Setting range is from 48.0V to 61.0V. Increment of each click is 0.1V. |
| 33 | Battery equalized time | 60min (default) 33 ⚙️ 60 | Setting range is from 5min to 900min. Increment of each click is 5min. |
| 34 | Battery equalized timeout | 120min (default) 34 ⚙️ 120 | Setting range is from 5min to 900 min. Increment of each click is 5 min. |
| 35 | Equalization interval | 30days (default) 35 ⚙️ 30d | Setting range is from 0 to 90 days. Increment of each click is 1 day |

| | | | |
|----|---|---|--|
| 51 | On/Off control for RGB LED *It's necessary to enable this setting to activate RGB LED lighting function. | Enabled (default) 51  LEN | Disable 51  LdS |
| 52 | Brightness of RGB LED | Low 52  LO | Normal (default) 52  n0t |
| | | High 52  HI | |
| 53 | Color of RGB LED | Green (default) 53  GrE | Red 53  rEd |
| | | Blue 53  bLU | Yellow 53  yEL |
| | | White 53  wHI | |
| 60 | Low DC cut off voltage or SOC percentage on second output (L2) | 24V default setting: 21.0V 60  <hr/> BATT 21.0 _v | If "User-defined" is selected in program 05, this setting range is from 21.0V to 31.0V. Increment of each click is 0.1V. |

| | | | |
|----|---|--|---|
| | | <p>48V default setting: 42.0V</p>  | <p>If "User-defined" is selected in program 05, this setting range is from 42.0V to 60.0V. Increment of each click is 0.1V.</p> |
| | | <p>SOC 0% (default for Lithium)</p>  | <p>If any type of lithium battery is selected in program 05, this parameter value will be displayed in percentage and value setting is based on battery capacity percentage. Setting range is from 0% to 95%. Increment of each click is 5%.</p> |
| 61 | Setting discharge time on the second output (L2) | <p>Disable (Default)</p>  | <p>Setting range is disable and then from 0 min to 990 min. Increment of each click is 5 min.</p> <p>*If the battery discharge time achieves the setting time in program 61 and the program 60 function is not triggered, the output will be turned off.</p> |
| 62 | Setting time interval to turn on second output (L2) | <p>00~23 (Default. Second output is always on)</p>  | <p>Setting range is from 00 to 23. Increment of each click is 1 hour. If setting range is from 00 to 08, the second output will be turned on until 09:00. During this period, it will be turned off if any setting value in program 60 or 61 is reached.</p> |
| 63 | Setting voltage point or SOC to restart on the second output (L2) | <p>Default setting: 46.0V</p>  | <p>If "User-defined" is selected in program 05, this setting range is from 21.5V to 31.5V for 4K model and 43.0V to 61.0V for 6K model. Increment of each click is 0.1V.</p> <p>*If second output is cut off due to setting in program 60, second output (L2) will restart according to setting in program 63.</p> |
| | | <p>SOC: 20% (default for lithium battery)</p>  | <p>If any type of lithium battery is selected in program 05, this parameter value will be displayed in percentage and value setting is based on battery capacity percentage. Setting range is from 5% to 100%. Increment of each click is 5%.</p> <p>*If second output is cut off due to setting in program 60, second output (L2) will restart according to setting in program 63.</p> |



| | | | |
|----|--|--|---|
| 64 | Setting waiting time to turn on the second output (L2) when the inverter is back to Line Mode or battery is in charging status | 0 min (Default) 64  0 | Setting range is from 0 min to 990 min. Increment of each click is 5 min. *If second output is cut off due to setting in program 61, second output (L2) will restart according to setting in program 64. |
| 93 | Erase all data log | Not reset(Default) 93  n7t | Reset 93  t5t |
| 94 | Data log recorded interval *The maximum data log number is 1440. If it's over 1440, it will re-write the first log. | 3 minutes 94  3 | 5 minutes 94  5 |
| | | 10 minutes (default) 94  10 | 20 minutes 94  20 |
| | | 30 minutes 94  30 | 60 minutes 94  60 |
| 95 | Time setting – Minute | For minute setting, the range is from 0 to 59. 95   n1n 0 | |
| 96 | Time setting – Hour | For hour setting, the range is from 0 to 23. 96   HOV 0 | |






| | | |
|----|---------------------|--|
| 97 | Time setting– Day | <p>For day setting, the range is from 1 to 31.</p>  |
| 98 | Time setting– Month | <p>For month setting, the range is from 1 to 12.</p>  |
| 99 | Time setting – Year | <p>For year setting, the range is from 17 to 99.</p>  |

Functional Setting














There are three function keys on the display panel to implement special functions such as USB OTG, timer setting for output source priority and timer setting for charger source priority.

1. USB Function Setting

Insert an OTG USB disk into the USB port (). Press and hold "/U" button for 3 seconds to enter USB Setup Mode. These functions including inverter firmware upgrade, data log export and internal parameters re-write from the USB disk.

| Procedure | LCD Screen |
|---|---|
| Step 1: Press and hold "  /U" button for 3 seconds to enter USB function setting mode. |  |
| Step 2: Press "  /U", "  /A" or "  /Z" button to enter the selectable setting programs (detail descriptions in Step 3). | |

Step 3: Please select setting program by following the procedure.

| Program# | Operation Procedure | LCD Screen |
|---|---|---|
|  /U: Upgrade firmware | This function is to upgrade inverter firmware. If firmware upgrade is needed, please check with your dealer or installer for detail instructions. | |
|  /A: Re-write internal parameters | This function is to over-write all parameter settings (TEXT file) with settings in the On-The-Go USB disk from a previous setup or to duplicate inverter settings. Please check with your dealer or installer for detail instructions. | |
|  /Z: Export data log | By pressing "  /Z" button to export data log from the inverter to USB disk. If the selected function is ready, LCD will display "Fdy". Press "  /U" button to confirm the selection again. |   |
| | <ul style="list-style-type: none"> Press "/A" button to select "Yes", LED 1 will flash once every second during the process. It will only display LOG and all LEDs will be on after this action is complete. Then, press "/U" button to return to main screen. Or press "/Z" button to select "No" to return to main screen. |    |

If no button is pressed for 1 minute, it will automatically return to main screen.

Error message for USB On-The-Go functions:

| Error Code | Messages |
|------------|---|
| U01 | No USB disk is detected. |
| U02 | USB disk is protected from copying. |
| U03 | Document inside the USB disk contains the wrong format. |

If any error occurs, error code will only show for 3 seconds. After 3 seconds, it will automatically return to the main screen.

2. Timer Setting for Output Source Priority

This timer setting is to set up the output source priority per day.

| Procedure | LCD Screen |
|---|------------|
| Step 1: Press and hold "☰/☒" button for 3 seconds to enter Timer Setup Mode for output source priority. | USb ⚙️ |
| Step 2: Press "☰/☒", "☰/☑" or "☰/☒" button to enter the selectable programs (detail descriptions in Step 3). | SUB SbU |

Step 3: Please select setting program by following each procedure.

| Program# | Operation Procedure | LCD Screen |
|----------|---|--------------------|
| ☰/☒ | Press "☰/☒" button to set up Utility First Timer. Press "☰/☑" button to select starting time. Press "▲" or "▼" button to adjust values and press "←" to confirm. Press "☰/☒" button to select end time. Press "▲" or "▼" button to adjust values, press "←" button to confirm. The setting values are from 00 to 23, with 1-hour increment. | USb ⚙️ 00 23 |
| ☰/☑ | Press "☰/☑" button to set up Solar First Timer. Press "☰/☑" button to select starting time. Press "▲" or "▼" button to adjust values and press "←" to confirm. Press "☰/☒" button to select end time. Press "▲" or "▼" button to adjust values, press "←" button to confirm. The setting values are from 00 to 23, with 1-hour increment. | SUB ⚙️ 00 23 |
| ☰/☒ | Press "☰/☒" button to set up SBU Priority Timer. Press "☰/☑" button to select starting time. Press "▲" or "▼" button to adjust values and press "←" to confirm. Press "☰/☒" button to select end time. Press "▲" or "▼" button to adjust values, press "←" button to confirm. The setting values are from 00 to 23, with 1-hour increment. | SbU ⚙️ 00 23 |


































Press "☰/☒" button to exit the Setup Mode.


3. Timer Setting for the Charger Source Priority

This timer setting is to set up the charger source priority per day.

| Procedure | LCD Screen |
|---|------------|
| Step 1: Press and hold "☰/☒" button for 3 seconds to enter Timer Setup Mode for charging source priority. | CS0 ⚙️ |
| Step 2: Press "☰/☒", "☰/☑" or "☰/☒" button to enter the selectable programs (detail descriptions in Step 3). | SNU OS0 |



Step 3: Please select setting program by following each procedure.







| Program# | Operation Procedure | LCD Screen |
|---|---|---|
|  | Press "  " button to set up Solar First Timer. Press "  " button to select starting time. Press "  " or "  " button to adjust values and press "  " to confirm. Press "  " button to select end time. Press "  " or "  " button to adjust values, press "  " button to confirm. The setting values are from 00 to 23, with 1-hour increment. |  |
|  | Press "  " button to set up Solar & Utility Timer. Press "  " button to select starting time. Press "  " or "  " button to adjust values and press "  " to confirm. Press "  " button to select end time. Press "  " or "  " button to adjust values, press "  " button to confirm. The setting values are from 00 to 23, with 1-hour increment. |  |
|  | Press "  " button to set up Solar Only Timer. Press "  " button to select starting time. Press "  " or "  " button to adjust values and press "  " to confirm. Press "  " button to select end time. Press "  " or "  " button to adjust values, press "  " button to confirm. The setting values are from 00 to 23, with 1-hour increment. |  |



















Press "" button to exit the Setup Mode.







Display Setting







The LCD display information will be switched in turn by pressing the "UP" or "DOWN" button. The selective information will be switched as per the following orders:





| Selectable information | LCD display |
|--|--|
| Input voltage/Output voltage (Default Display Screen) | <p>Input Voltage=230V, output voltage=230V</p>  <p>The diagram shows a power flow from AC input through MPPT, AC/DC, and DC/DC stages to a battery (BATT) and a load. A BYPASS path is also shown.</p> |
| Input frequency | <p>Input frequency=50Hz</p>  <p>The diagram is identical to the one above, showing the power conversion process.</p> |

| | |
|-------------------------|--|
| <p>PV voltage</p> | <p>PV voltage=260V</p>  |
| <p>PV current</p> | <p>PV current = 2.5A</p>  |
| <p>PV power</p> | <p>PV power = 500W</p>  |
| <p>Charging current</p> | <p>AC and PV charging current=50A</p>  <p>PV charging current=50A</p>  <p>AC charging current=50A</p>  |

| | |
|---|--|
| <p>Charging power</p> | <p>AC and PV charging power=500W LOAD </p> <p> 500 W OUTPUT 230 V</p> <p></p> <p>PV charging power=500W LOAD </p> <p> 500 W OUTPUT 230 V</p> <p></p> <p>AC charging power=500W LOAD </p> <p> 500 W OUTPUT 230 V</p> <p></p> |
| <p>Battery voltage and output voltage</p> | <p>Battery voltage=25.5V, output voltage=230V LOAD </p> <p> 25.5 V OUTPUT 230 V</p> <p></p> |
| <p>Output frequency</p> | <p>Output frequency=50Hz LOAD </p> <p> 25.5 V OUTPUT 50 Hz</p> <p></p> |
| <p>Load percentage</p> | <p>Load percent=70% LOAD </p> <p> 25.5 V OUTPUT 70 %</p> <p></p> |






| | |
|--------------------------|---|
| <p>Load in VA</p> | <p>When connected load is lower than 1kVA, load in VA will present xxxVA like below chart.</p>  <p>When load is larger than 1kVA ($\geq 1\text{kVA}$), load in VA will present x.xkVA like below chart.</p>  |
| <p>Load in Watt</p> | <p>When load is lower than 1kW, load in W will present xxxW like below chart.</p>  <p>When load is larger than 1kW ($\geq 1\text{kW}$), load in W will present x.xkW like below chart.</p>  |
| <p>L2 output voltage</p> | <p>Second output is off and L2 output voltage is 0V.</p>  <p>Second output is on and L2 output voltage is 230V.</p>  |





| | |
|--|---|
| <p>Battery voltage/DC discharging current</p> | <p>Battery voltage=25.5V, discharging current=1A</p>  |
| <p>PV energy generated today and Load output energy today</p> | <p>PV energy generation today = 3.88kWh, Today load output energy= 9.88kWh.</p>  |
| <p>PV energy generated this month and Load output energy this month.</p> | <p>PV energy generation this month = 388kWh, Load output energy this month= 988kWh.</p>  |
| <p>PV energy generated this year and Load output energy this year.</p> | <p>PV energy generation this year = 3.88MWh, Load output energy this year = 9.88MWh.</p>  |
| <p>Total PV energy generation and total load output energy.</p> | <p>Total PV energy generation = 38.8MWh, Total load output energy = 98.8MWh.</p>  |
| <p>Real date.</p> | <p>Real date Nov 28, 2020.</p>  |

| | |
|--|---|
| <p>Real time.</p> | <p>Real time 13:20.</p>  |
| <p>Main CPU version checking.</p> | <p>Main CPU version 00014.04.</p>  |
| <p>Secondary CPU version checking.</p> | <p>Secondary CPU version 00003.03.</p>  |
| <p>Wi-Fi version checking.</p> | <p>Wi-Fi version 00000.24.</p>  |

Operating Mode Description

| Operation mode | Description | LCD display |
|--|---|---|
| <p>Standby mode</p> <p>Note:</p> <p>*Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output.</p> | <p>No output is supplied by the unit but it still can charge batteries.</p> | <p>Charging by utility and PV energy.</p> |
| | | <p>Charging by utility.</p> |
| | | <p>Charging by PV energy.</p> |
| | | <p>No charging.</p> |
| <p>Fault mode</p> <p>Note:</p> <p>*Fault mode: Errors are caused by inside circuit error or external reasons such as over temperature, output short circuited and so on.</p> | <p>No charging at all no matter if grid or PV power is available.</p> | <p>Grid and PV power are available.</p> |
| | | <p>Grid is available.</p> |
| | | <p>PV power is available.</p> |
| | | <p>No charging.</p> |

| | | |
|------------------|---|--|
| <p>Line Mode</p> | <p>The unit will provide output power from the mains. It will also charge the battery at line mode.</p> | <p>Charging by utility and PV energy.</p>  |
| | | <p>Charging by utility.</p>  |
| | | <p>If "SUB" (solar first) is selected as output source priority and solar energy is not sufficient to provide the load, solar energy and the utility will provide the loads and charge the battery at the same time.</p>  |
| | | <p>If either "SUB" (solar first) or "SBU" is selected as output source priority and battery is not connected, solar energy and the utility will provide the loads.</p>  |
| | | <p>Power from utility.</p>  |

| | | |
|---------------------|---|--|
| <p>Battery Mode</p> | <p>The unit will provide output power from battery and/or PV power.</p> | <p>Power from battery and PV energy.</p>  |
| | | <p>PV energy will supply power to the loads and charge battery at the same time. No utility is available.</p>  |
| | | <p>Power from battery only.</p>  |
| | | <p>Power from PV energy only.</p>  |

Battery Equalization Description

Battery equalization function is built into the charge controller. It reverses the buildup of negative chemical effects such as stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that may have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize the battery periodically.


- **How to Activate Equalization Function**

You must enable battery equalization function in LCD setting Program 30 first. You can then apply this function by either one of the following methods:

1. Setting equalization interval in Program 35.
2. Activate equalization immediately in Program 36.


- **When to Equalize**

In floating charge stage, when setting the equalization interval (battery equalization cycle) is reached, or equalization is activated immediately, the controller will start to enter Equalize Mode.




- **Equalize Charging and Timeout**

In Equalize Mode, the controller will supply power to charge battery as much as possible until battery voltage reach the equalization voltage. Then, constant-voltage regulation is applied to maintain battery voltage at the equalization level. The battery will remain in the Equalize Mode until the equalization timer runs out.















However, in Equalize Mode, if the battery equalization timer runs out and the battery voltage doesn't recover to the battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves equalization voltage. If the battery voltage is still lower than equalization voltage when the extension runs out, the charge controller will stop equalization and return to the floating charging stage.



Fault Reference Code

| Fault Code | Fault Event | Icon on |
|------------|--|---------|
| 01 | Fan is locked when inverter is off. | F01 |
| 02 | Over temperature | F02 |
| 03 | Battery voltage is too high | F03 |
| 04 | Battery voltage is too low | F04 |
| 05 | Output short circuited or over temperature is detected by internal converter components. | F05 |
| 06 | Output voltage is too high. | F06 |
| 07 | Overload time out | F07 |
| 08 | Bus voltage is too high | F08 |
| 09 | Bus soft start failed | F09 |
| 51 | Over current or surge | F51 |
| 52 | Bus voltage is too low | F52 |
| 53 | Inverter soft start failed | F53 |
| 55 | Over DC voltage in AC output | F55 |
| 57 | Current sensor failed | F57 |
| 58 | Output voltage is too low | F58 |
| 59 | PV voltage is over limitation | F59 |

Warning Indicator

| Warning Code | Warning Event | Audible Alarm | Icon flashing |
|--------------|---|-------------------------------|--|
| 01 | Fan is locked when inverter is on. | Beep three times every second | 01  |
| 02 | Over temperature | None | 02  |
| 03 | Battery is over-charged | Beep once every second | 03  |
| 04 | Low battery | Beep once every second | 04  |
| 07 | Overload | Beep once every 0.5 second | 07   |
| 10 | Output power derating | Beep twice every 3 seconds | 10  |
| 15 | PV energy is low. | Beep twice every 3 seconds | 15  |
| 16 | High AC input (>280VAC) during BUS soft start | None | 16  |
| 32 | Communication failure between inverter and remote display panel | None | 32  |
| E9 | Battery equalization | None | E9  |
| bP | Battery is not connected | None | bP  |


CLEARANCE AND MAINTENANCE FOR ANTI-DUST KIT

Overview


Every inverter is already installed with anti-dusk kit from factory. This kit also keeps dusk from your inverter and increases product reliability in harsh environment.

Clearance and Maintenance

Step 1: Please remove the screws on the sides of the inverter.



Step 2: Then, dustproof case can be removed and take out air filter foam as shown in below chart.



Step 3: Clean air filter foam and dustproof case. After clearance, re-assemble the dust-kit back to the inverter.

NOTICE: The anti-dust kit should be cleaned from dust every one month.

SPECIFICATIONS

Table 1 Line Mode Specifications

| INVERTER MODEL | 4KW | 6KW |
|---|--|-----|
| Input Voltage Waveform | Sinusoidal (utility or generator) | |
| Nominal Input Voltage | 230Vac | |
| Low Loss Voltage | 170Vac±7V (UPS); 90Vac±7V (Appliances) | |
| Low Loss Return Voltage | 180Vac±7V (UPS); 100Vac±7V (Appliances) | |
| High Loss Voltage | 280Vac±7V | |
| High Loss Return Voltage | 270Vac±7V | |
| Max AC Input Voltage | 300Vac | |
| Nominal Input Frequency | 50Hz / 60Hz (Auto detection) | |
| Low Loss Frequency | 40±1Hz | |
| Low Loss Return Frequency | 42±1Hz | |
| High Loss Frequency | 65±1Hz | |
| High Loss Return Frequency | 63±1Hz | |
| Output Short Circuit Protection | Circuit Breaker | |
| Efficiency (Line Mode) | >95% (Rated R load, battery full charged) | |
| Transfer Time | 10ms typical (UPS); 20ms typical (Appliances) | |
| <p>Output power derating: When AC input voltage drops to 170V, the output power will be derated.</p> | | |

Table 2 Inverter Mode Specifications

| INVERTER MODEL | 4KW | 6KW |
|---|-----------------------------------|--------------------|
| Rated Output Power | 4KVA/4KW | 6KVA/6KW |
| Output Voltage Waveform | Pure Sine Wave | |
| Output Voltage Regulation | 230Vac±10% | |
| Output Frequency | 50Hz | |
| Peak Efficiency | 93% | |
| Overload Protection | 5s@≥110% load; 10s@105%~110% load | |
| Surge Capacity | 2* rated power for 5 seconds | |
| Max. AC Output Current | 30Amp | 40Amp |
| Nominal DC Input Voltage | 24Vdc | 48Vdc |
| Cold Start Voltage | 23.0Vdc | 46.0Vdc |
| Low DC Warning Voltage @ load < 50% @ load ≥ 50% | 23.0Vdc 22.0Vdc | 46.0Vdc 44.0Vdc |
| Low DC Warning Return Voltage @ load < 50% @ load ≥ 50% | 23.5Vdc 23.0Vdc | 47.0Vdc 46.0Vdc |
| Low DC Cut-off Voltage @ load < 50% @ load ≥ 50% | 21.5Vdc 21.0Vdc | 43.0Vdc 42.0Vdc |
| High DC Recovery Voltage | 32Vdc | 62Vdc |
| High DC Cut-off Voltage | 33Vdc | 63Vdc |
| No Load Power Consumption | <40W | <55W |
| Power Limitation When battery voltage is lower than 25V for 4K model and 54V for 6K model, output power will be de-rated. If connected output load is higher than minimum output rated power (3KW for 4K model and 4.6KW for 6K model) at the same time, the AC output voltage will drop until the output power reduce to minimum power. The lowest AC output voltage is 225V when setting output voltage is 240V and 215V when setting output voltage is 220V or 230V. | <p>4K</p> <p>6K</p> | |

Table 3 Charge Mode Specifications

| Utility Charging Mode | | |
|--|------------------------------------|---------|
| INVERTER MODEL | 4KW | 6KW |
| Charging Algorithm | 3-Step | |
| AC Charging Current (Max) | 100Amp (@ $V_{I/P}=230V_{ac}$) | |
| Bulk Charging Voltage | Flooded Battery | 29.2Vdc |
| | AGM / Gel Battery | 28.2Vdc |
| Floating Charging Voltage | 27Vdc | 54Vdc |
| Charging Curve | | |
| MPPT Solar Charging Mode | | |
| INVERTER MODEL | 4KW | 6KW |
| Max. PV Array Power | 5000W | 6000W |
| Max. PV Current | 27A | |
| Nominal PV Voltage | 320Vdc | 360Vdc |
| Start-up Voltage | 60Vdc +/- 10Vdc | |
| PV Array MPPT Voltage Range | 60Vdc~450Vdc | |
| Max. PV Array Open Circuit Voltage | 500Vdc | |
| Max Charging Current (AC charger plus solar charger) | 120Amp | |

Table 4 General Specifications

| INVERTER MODEL | 4KW | 6KW |
|-----------------------------|--|-----|
| Operating Temperature Range | -10°C to 50°C | |
| Storage temperature | -15°C~ 60°C | |
| Humidity | 5% to 95% Relative Humidity (Non-condensing) | |
| Dimension (D*W*H), mm | 115 x 300 x 435 | |
| Net Weight, kg | 9 | 10 |

TROUBLE SHOOTING

| Problem | LCD/LED/Buzzer | Explanation / Possible cause | What to do |
|---|---|---|--|
| Unit shuts down automatically during startup process. | LCD/LEDs and buzzer will be active for 3 seconds and then complete off. | The battery voltage is too low (<1.91V/Cell) | 1. Re-charge battery. 2. Replace battery. |
| No response after power on. | No indication. | 1. The battery voltage is far too low. (<1.4V/Cell) 2. Internal fuse tripped. | 1. Contact repair center for replacing the fuse. 2. Re-charge battery. 3. Replace battery. |
| Mains exist but the unit works in battery mode. | Input voltage is displayed as 0 on the LCD and green LED is flashing. | Input protector is tripped | Check if AC breaker is tripped and AC wiring is connected well. |
| | Green LED is flashing. | Insufficient quality of AC power. (Shore or Generator) | 1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS→Appliance) |
| | Green LED is flashing. | Set "SUB" (solar first) as the priority of output source. | Change output source priority to "USB" (utility first). |
| When the unit is turned on, internal relay is switched on and off repeatedly. | LCD display and LEDs are flashing | Battery is disconnected. | Check if battery wires are connected well. |
| Buzzer beeps continuously and red LED is on. | Fault code 07 | Overload error. The inverter is overload 110% and time is up. | Reduce the connected load by switching off some equipment. |
| | | If PV input voltage is higher than specification, the output power will be derated. At this time, if connected loads is higher than derated output power, it will cause overload. | Reduce the number of PV modules in series or the connected load. |
| | Fault code 05 | Output short circuited. | Check if wiring is connected well and remove abnormal load. |
| | | Temperature of internal converter component is over 120°C. | Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| | Fault code 02 | Internal temperature of inverter component is over 100°C. | |
| | Fault code 03 | Battery is over-charged. | Return to repair center. |
| | | The battery voltage is too high. | Check if spec and quantity of batteries are meet requirements. |
| | Fault code 01 | Fan fault | Replace the fan. |
| | Fault code 06/58 | Output abnormal (Inverter voltage below than 190Vac or is higher than 260Vac) | 1. Reduce the connected load. 2. Return to repair center |
| | Fault code 08/09/53/57 | Internal components failed. | Return to repair center. |
| | Fault code 51 | Over current or surge. | Restart the unit, if the error happens again, please return to repair center. |
| | Fault code 52 | Bus voltage is too low. | |
| Fault code 55 | Output voltage is unbalanced. | | |
| Fault code 59 | PV input voltage is beyond the specification. | Reduce the number of PV modules in series. | |

Appendix I: BMS Communication Installation

1. Introduction


If connecting to lithium battery, it is recommended to purchase a custom-made RJ45 communication cable. Please check with your dealer or integrator for details.

This custom-made RJ45 communication cable delivers information and signal between lithium battery and the inverter. These information are listed below:

- Re-configure charging voltage, charging current and battery discharge cut-off voltage according to the lithium battery parameters.
- Have the inverter start or stop charging according to the status of lithium battery.


2. Pin Assignment for BMS Communication Port

| | Definition |
|-------|------------|
| PIN 1 | RS232TX |
| PIN 2 | RS232RX |
| PIN 3 | RS485B |
| PIN 4 | NC |
| PIN 5 | RS485A |
| PIN 6 | CANH |
| PIN 7 | CANL |
| PIN 8 | GND |




3. Lithium Battery Communication Configuration

LIO-4805/LIO-4810-150A




ESS LIO-I 4810



ID Switch indicates the unique ID code for each battery module. It's required to assign an identical ID to each battery module for normal operation. We can set up the ID code for each battery module by rotating the PIN number on the ID switch. From number 0 to 9, the number can be random; no particular order. Maximum 10 battery modules can be operated in parallel.

PYLONTECH



① Dip Switch: There are 4 Dip Switches that sets different baud rate and battery group address. If switch position is turned to the "OFF" position, it means "0". If switch position is turned to the "ON" position, it means "1".

Dip 1 is "ON" to represent the baud rate 9600.

Dip 2, 3 and 4 are reserved for battery group address.

Dip switch 2, 3 and 4 on master battery (first battery) are to set up or change the group address.

NOTE: "1" is upper position and "0" is bottom position.

| Dip 1 | Dip 2 | Dip 3 | Dip 4 | Group address |
|---|-------|-------|-------|--|
| 1: RS485 baud rate=9600 Restart to take effect | 0 | 0 | 0 | Single group only. It's required to set up master battery with this setting and slave batteries are unrestricted. |
| | 1 | 0 | 0 | Multiple group condition. It's required to set up master battery on the first group with this setting and slave batteries are unrestricted. |
| | 0 | 1 | 0 | Multiple group condition. It's required to set up master battery on the second group with this setting and slave batteries are unrestricted. |
| | 1 | 1 | 0 | Multiple group condition. It's required to set up master battery on the third group with this setting and slave batteries are unrestricted. |
| | 0 | 0 | 1 | Multiple group condition. It's required to set up master battery on the fourth group with this setting and slave batteries are unrestricted. |
| | 1 | 0 | 1 | Multiple group condition. It's required to set up master battery on the fifth group with this setting and slave batteries are unrestricted. |


NOTE: The maximum groups of lithium battery is 5 and for maximum number for each group, please check with battery manufacturer.

4. Installation and Operation

LIO-4805/LIO-4810-150A/ESS LIO-I 4810

After ID no. is assigned for each battery module, please set up LCD panel in inverter and install the wiring connection as following steps.


Step 1: Use supplied RJ11 signal cable to connect into the extension port (P1 or P2).



Step 6. Be sure to select battery type as "LIB" in LCD program 5.

05 ⚙️


LIB

If communication between the inverter and battery is successful, the battery icon  on LCD display will flash. Generally speaking, it will take longer than 1 minute to establish communication.


PYLONTECH

After configuration, please install LCD panel with inverter and Lithium battery with the following steps.


Step 1. Use custom-made RJ45 cable to connect inverter and Lithium battery.




Step 2. Switch on Lithium battery.




Step 3. Press more than three seconds to start Lithium battery. Output power is ready.



Step 4. Turn on the inverter.




Step 5. Be sure to select battery type as "PYL" in LCD program 5.

05 

PYL




If communication between the inverter and battery is successful, the battery icon  on LCD display will flash. Generally speaking, it will take longer than 1 minute to establish communication.

Active Function


This function is to activate lithium battery automatically while commissioning. After battery wiring and commissioning is successfully, if battery is not detected, the inverter will automatically activate battery if the inverter is powered on.

WECO


Step 1. Use a custom-made RJ45 cable to connect inverter and Lithium battery.



Step 2. Switch on Lithium battery.




Step 3. Turn on the inverter.



Step 4. Be sure to select battery type as "WEC" in LCD program 5.


05 

WEC


If communication between the inverter and battery is successful, the battery icon  on LCD display will "flash". Generally speaking, it will take longer than 1 minute to establish communication.

SOLTARO


Step 1. Use a custom-made RJ45 cable to connect inverter and Lithium battery.



Step 2. Open DC isolator and switch on Lithium battery.




Step 3. Turn on the inverter.



Step 4. Be sure to select battery type as "SOL" in LCD program 5.


05 

SOL

If communication between the inverter and battery is successful, the battery icon  on LCD display will "flash". Generally speaking, it will take longer than 1 minute to establish communication.








5. LCD Display Information

Press "▲" or "▼" button to switch LCD display information. It will show battery pack and battery group number before "Main CPU version checking" as shown below.

| Selectable information | LCD display |
|--|---|
| Battery pack numbers & Battery group numbers | Battery pack numbers = 3, battery group numbers = 1  |

5. Code Reference

Related information code will be displayed on LCD screen. Please check inverter LCD screen for the operation.

| Code | Description | Action |
|---|--|--|
|  | If battery status is not allowed to charge and discharge after the communication between the inverter and battery is successful, it will show code 60 to stop charging and discharging battery. | |
|  | <p>Communication lost (only available when the battery type is setting as any type of lithium-ion battery.)</p> <ul style="list-style-type: none"> • After battery is connected, communication signal is not detected for 3 minutes, buzzer will beep. After 10 minutes, inverter will stop charging and discharging to lithium battery. • Communication lost occurs after the inverter and battery is connected successfully, buzzer beeps immediately. | |
|  | Battery number is changed. It probably is because of communication lost between battery packs. | <p>Press "UP" or "DOWN" key to switch LCD display until below screen shows. It will have battery number re-checked and 62 warning code will be clear.</p>  |
|  | If battery status is not allowed to charge after the communication between the inverter and battery is successful, it will show code 69 to stop charging battery. | |
|  | If battery status must to be charged after the communication between the inverter and battery is successful, it will show code 70 to charge battery. | |
|  | If battery status is not allowed to discharge after the communication between the inverter and battery is successful, it will show code 71 to stop discharging battery. | |

Appendix II: The Wi-Fi Operation Guide in Remote Panel

1. Introduction

MOTOMA is an energy storage system monitoring APP provided by Shenzhen Motoma Power Co., Ltd. The APP displays the current running status and data changes of the energy storage system in real time in charts, energy flow charts, lists and other ways.

The main features of the software are:

- The current running status and detailed data of the energy storage system are displayed in real time by charts, energy flow charts, and lists.
- Real-time data and historical data can be queried in time to master the operation status of the energy storage system anytime and anywhere.
- The Chinese and English interfaces are free to switch with the operating system language of the handheld device.



2. "MOTOMA" App

2-1. Download and install APP

Operating system requirement for your smart phone:

- 🍏 iOS system supports iOS 9.0 and above
- 🤖 Android system supports Android 5.0 and above

Please scan the following QR code with your smart phone and download "**MOTOMA**" App.



Android system




iOS system


Or you may find "**MOTOMA**" App from the Apple® Store.



2-2. Initial Setup

Step 1: Registration at first time

After the installation, please tap the shortcut icon  to access this APP on your mobile screen. In the screen, tap "Register" to access "User Registration" page. You can register by entering PN number, user name, password, email address, and mobile phone number. After the registration is successful, you can return to the login page to log in.




2-3. Equipment Distribution Network

- Network access

Entry 1: Login Page-toolbox-Wi-Fi distribution network"


Entry 2: Click "my" interface " → " Wi-Fi distribution network"



- **Wi-Fi network distribution process**


Step 1: connect the device

Open the "Wi-Fi" in the "Settings" of the mobile phone, connect the digital collector PN that needs to be allocated to the network, open the optical treasure APP, click the "toolbox", select the Wi-Fi distribution network to enter the distribution network page, click the "networking settings" to select the Wi-Fi and enter the password to connect.



Step 2: configure a network for the device

Enter the router name and password, or click the signal icon to view the nearby Wi-Fi network.




Note:

1. Please ensure that the signal connected to the network is good and the network is unblocked.
2. Currently, routers in 5G band are not supported. Please use routers in 2.4G Band.
3. Make sure that the router password is correct.


Step 3: view the distribution results

If the network configuration is successful, the datalogger restarts. After about 5 minutes, you can see the device data.



2-4. Login

After finishing the registration and local Wi-Fi configuration, enter registered name and password to login. Note: Tick "Remember Me" for your login convenience afterwards.




3. APP Main Function

3-1. Overview

Show all devices under the account, view the device status, current day earnings, current month earnings, current year earnings, PV current power, total CO2 emission reduction, and daily, monthly, and annual power generation, and display the chart.

- Blue indicates that the device is normal;
- Gray indicates that the device is offline;
- Red indicates equipment failure;
- Yellow indicates device alerts;
- Cyan indicates that the device is standby.



3-2. Device

Device List

Displays all devices under the account, and displays the status and basic parameters of the devices.



Add device


Step 1: Entry

On the devices page, click the Add + icon.



Step 2: Add a device

Complete the device information to add the device successfully.




Step 3: Add successfully

After the device is added, if the device does not have a network, data cannot be migrated to the cloud. If it is a WiFi device, you need to configure a network for the device.

Device Details


1. Energy flow diagram

You can view the energy status and parameters of the equipment. Click the solar inverter, power grid, and battery icons to view the relevant parameters of the equipment.




2. Data charts

You can view the area diagram of the power generation and load power of the equipment, and the column diagram of the monthly, annual and total power generation.




3. Parameter settings

You can Gou Xuan parameters by setting parameters. The Gou Xuan parameters are displayed directly, which is convenient for you to view some important parameters. Click reset to clear all Gou Xuan.




4. Parameter Analysis

You can select a parameter of the device for analysis.




5. Data details

You can view the data details recorded by the device every five minutes.



6. Equipment Control

This page is to activate some features and set up parameters for inverters. Please be noted that the listing in "Parameter Setting" page in below diagram may differ from the models of monitored inverter. Here will briefly highlight some of it, **【Output Setting】** , **【Battery Parameter Setting】** , **【Enable/ Disable items】** , **【Restore to the defaults】** to illustrate.



There are three ways to modify setting and they vary according to each parameter.

- Listing options to change values by tapping one of it.
- Activate/Shut down functions by clicking "Enable" or "Disable" button.
- Changing values by clicking arrows or entering the numbers directly in the column.

Each function setting is saved by clicking "Set" button.

Please refer to below parameter setting list for an overall description and be noted that the available parameters may vary depending on different models. Please always see the original product manual for detailed setting instructions.


Parameter setting list:

| Item | | Description |
|-----------------------------------|---|--|
| Output setting | Output source priority | To configure load power source priority. |
| | AC input range | When selecting "UPS", it's allowed to connect personal computer. Please check product manual for details. |
| | | When selecting "Appliance", it's allowed to connect home appliances. |
| | Output voltage | To set output voltage. |
| | Output frequency | To set output frequency. |
| L2 output (second output setting) | Battery cut off voltage/SOC L2 | To set the battery stop discharging voltage or SOC on L2 output. |
| | Discharge Time L2 | To set the battery stop discharging time on L2 output. |
| | Time Interval to turn on L2 | To set the time interval to turn on L2 output. |
| Battery parameter setting | Battery type: | To set connected battery type. |
| | Battery cut-off voltage/SOC | To set the battery stop discharging voltage or SOC. Please see product manual for the recommended voltage or SOC range based on connected battery type. |
| | Back to grid voltage/SOC | When "SBU" or "SOL" is set as output source priority and battery voltage is lower than this setting voltage or SOC, unit will transfer to line mode and the grid will provide power to load. |
| | Back to discharge voltage/SOC | When "SBU" or "SOL" is set as output source priority and battery voltage is higher than this setting voltage or SOC, battery will be allowed to discharge. |
| | Charger source priority: | To configure charger source priority. |
| Battery parameter setting | Max. charging current | It's to set up battery charging parameters. The selectable values in different inverter model may vary. Please see product manual for the details. |
| | Max. AC charging current: | |
| | Float charging voltage | |
| | Bulk charging voltage | It's to set up battery charging parameters. The selectable values in different inverter model may vary. Please see product manual for the details. |
| | Battery equalization | Enable or disable battery equalization function. |
| | Real-time Activate Battery Equalization | It's real-time action to activate battery equalization. |
| | Equalized Time Out | To set up the duration time for battery equalization. |
| | Equalized Time | To set up the extended time to continue battery equalization. |
| | Equalization Period | To set up the frequency for battery equalization. |
| | Equalization Voltage | To set up the battery equalization voltage. |
| Enable/Disable Functions | LCD Auto-return to Main screen | If enable, LCD screen will return to its main screen after one minute automatically. |
| | Fault Code Record | If enabled, fault code will be recorded in the inverter when any fault happens. |
| | Backlight | If disabled, LCD backlight will be off when panel button is not operated for 1 minute. |
| | Bypass Function | If enabled, unit will transfer to line mode when overload happened in battery mode. |

| | | |
|--------------------------|--|--|
| | Beeps while primary source interrupt | If enabled, buzzer will alarm when primary source is abnormal. |
| Enable/Disable Functions | Over Temperature Auto Restart | If disabled, the unit won't be restarted after over-temperature fault is solved. |
| | Overload Auto Restart | If disabled, the unit won't be restarted after overload occurs. |
| | Buzzer | If disabled, buzzer won't be on when alarm/fault occurred. |
| RGB LED Setting | Enable / Disable | Turn on or off RGB LEDs. |
| | Brightness | Adjust the brightness. |
| Restore to the default | This function is to restore all settings back to default settings. | |


7. Delete the device

After a device is deleted, the device is not displayed in the device list.




8. View the number of collectors

You can view the information of the Digital Collector and Digital Collector connected to the device.



9. Datalogger details


You can view the information of the datalogger and perform operations such as restarting, debugging, and deleting the datalogger.



3-3. Alarm

Alarm List


Displays all Alarm information under the current account. You can filter alarm information by date, alarm status, and alarm type.



3-4. Me


Change Avatar

Click the avatar to select a mobile phone photo or a photo to change the avatar.




Username

You can click the user name to enter the personal information page. You can modify personal information such as nicknames and passwords.



Version Update

After a new version is released, click Update to go to the mall to update the APP.



Clear Cache

Click clear cache to clear the APP cache.

